

# Side-By-Side Bath Tissue Dispenser Mounting Instructions

Dispenser Numbers: D67021 (Stainless), D67022 (White), D67023 (Black)

## Mounting Instructions

### Tools:

- Screwdriver
- Power Drill with appropriate drill size
- Pencil
- Level

### Step 1 – (refer to Fig. 1)

Measure a minimum of 17.5" minimum from the floor to the bottom of the dispenser.

### Step 2 – (refer to Fig. 2)

Drill a pilot hole for the first screw. Fasten the screw to the wall, leaving a gap between the screw and the wall for the dispenser to slide over.

### Step 3 – (refer to Fig. 2)

Place a level at the bottom of the dispenser to insure dispenser mounting will be correct. Mark the additional 3 mounting holes. Remove dispenser and drill pilot holes.

### Step 4 –

Re-hang the dispenser on the installed screw. Fasten remaining 3 mounting screws. Be sure to securely tighten all screws.

